Installation Instructions

安裝說明書

前下水箱架拉桿 #Q0374

Application 適用車型

Honda Odyssey '13- (RC1/RC2)

Components 內含配件

① Brace 結構桿.....

Caution 注意事項

- •Installation is recommended to be performed by licensed mechanics with necessary tools to ensure safety. Incorrect installation may cause injury, damage to the product or vehicle. 安裝建議由合格的技師及工具執行以確保安全・安裝錯誤可能對人員、產品及車輛造成傷害。
- •Note the routing of wires and cables before installation, or please refer to factory manual. 安裝前請事先記下線路的安裝路徑及位置以維持原廠配置,有疑問時請參考原廠手冊
- •Tighten bolts and nuts frimly by using handtools, and with specified torque if mentioned. 安裝過程請使用手動工具確實鎖緊螺帽及螺絲·如有特別註明請依照說明指示的扭力上鎖。

Instructions 安裝說明

- 1. Remove the bolts on both sides . (See figure 1&2) 拆卸兩側螺絲。(參考圖表一、二)
- 2. Position the brace on the vehicle. 安裝結構桿。
- 3. Reinstall the bolts to secure the brace. 鎖回螺絲以將桿身固定。



See figure 2 (參考圖表二)



See figure 1 (參考圖表一)



■Illstration of installed state 安裝完成示意圖







